

315C & 250C Stack - Installation Instruction

- 1) Inspect collar to ensure springs, fuse-links and intumescent material have not been damaged during transport.
- 2) Secure collar to formwork.
- 3) Slab must be 150mm minimum thickness. Please see drawing for minimum height and diameter of concrete hob.
- 5) Cut off plastic top and place Backing Rod in penetration around the pipe before backfilling with sand/cement mix to prevent concrete entering the body of the collar.
- 5) After installation, ensure all spring pockets and Fuse-links are free from any cement slurry.

